Manual Supplement

Manual Title:	1760 Getting Started	Supplement Issue:	**3**
Part Number:	2713103	Issue Date:	2/21
Print Date:	June 2006	Page Count:	3
Revision/Date:	2, 7/10		

This supplement contains information necessary to ensure the accuracy of the above manual.

© 2011-2014 Fluke Corporation. All rights reserved.

FLUKE®

Change #1, A157

On page 6, replace Figure 2 with:



emv02.wmf

Figure 2. Instrument Label

On page 7, replace Figure 3 with:



emv03.bmp

Figure 3. Battery Label

Change #2, A157

On page 1, under ***Safety Instructions***, replace the first sentence with:

The design and manufacture of the device conform to the latest state of technology and the safety standards laid down in IEC 61010-1 and IEC 61010-2-30.

On page 2, add the following to the Symbols table:

	Consult user documentation..
	Conforms to relevant South Korean EMC Standards.
CAT II	MEASUREMENT CATEGORY II is applicable to test and measuring circuits connected directly to utilization points (socket outlets and similar points) of the low-voltage MAINS installation.
CAT III	MEASUREMENT CATEGORY III is applicable to test and measuring circuits connected to the distribution part of the building's low-voltage MAINS installation.
CAT IV	MEASUREMENT CATEGORY IV is applicable to test and measuring circuits connected at the source of the building's low-voltage MAINS installation.

On page 8, replace the 7th bullet with:

1 crossover Ethernet cable for direct-PC connection (RJ45 crossover cable, do not use the gray plug).

On page 14, under ***Communicating with the Recorder***, replace the second paragraph with:

Supply the Recorder with mains power, switch it on, connect a voltage sensor to channel 1 and connect the network interface to your PC using the Ethernet cable for direct connection (RJ45 crossover cable, do not use the gray plug).